

## **What To Do Before Your Template**

- **Make sure cabinets are 100% installed. There will be a return fee charge if they are not ready. If you do move any cabinets please let us know so we can come back out to re-measure.**
- **If you are supplying your own sink please have that and your faucets at the house. Always check your sink to make sure there is no damage.**
- **We would prefer that you would have your cooktop there. If it is not there, we will have to reschedule to come back out to re-measure the cooktop.**
- **Please have your countertops cleared off and wiped down in case we need to do a cardboard template.**

## **Getting Ready For A Tear Out / Install**

- **Have the cooktop and plumbing all remove and unhooked.**
- **Have everything removed off of your counter tops before the installers get there with the new counter tops.**
- **We are NOT responsible for any tile damages.**
- **The cabinet under the sink needs to be 100% cleared out.**
- **Please take up any rugs that the installers could slide on.**
- **If you do your own tear out, please make sure the excess glues is cleaned off the cabinets.**
- **All appliances are required to be there before the install, if not there will be an additional trip charge if we have to come back.**

**• WE SUGGEST LETTING YOUR SINK SET FOR AT LEAST 24 HOURS BEFORE PLUMBING IS HOOKED UP.**

**• CNC GRANITE DOES NOT DO ANY PLUMBING**

**• CNC GRANITE DOES NOT UNHOOK OR REHOOK ANY KIND OF COOKTOPS OR MOVE OUT ANY APPLIANCES.**